

# Master

## SELECT ACCESS™ Lock®

Model: #5400D

### Instructions:

#### Opening the key storage compartment door

1. Open shutter door to reveal the dials and the release button
2. Rotate dials to the current combination (if the lock is new, the combination is set at the factory to 0-0-0-0)
3. Press down on the release button to open the door
4. Pull the door fully open
5. Add or remove keys
6. Close compartment door
7. Scramble the combination dials to lock the door and conceal your combination (A)
8. Close the shutter door (B)

Release button found behind shutter door



#### To set a new combination:

#### *The initial combination is set at the factory to 0-0-0-0*

1. Open the compartment door (see instructions above)
2. Push the reset lever left and down. The lever remains in this position
3. Rotate dials to your desired combination
4. Push the reset lever, up and right, back to the original position
5. Close the key storage compartment door
6. Scramble the combination dials to lock the door and conceal your combination (A)
7. Close the shutter door (B)

Key Storage compartment



Reset Lever



### Removing Lockbox

1. Open the compartment door (see instructions above)
2. Push the shackle release lever to the left to open shackle
3. Pull shackle around and out the lock, place shackle around door knob
4. Close the shackle to lock
5. Close the compartment
6. Scramble the combination dials to lock the door and conceal your combination
7. Close the shutter door



Shackle Release Lever



#### Reminder:

- (A) The release button will open the lock until you scramble the dials
- (B) Keep the shutter door closed to increase the weather resistance